



UTTERMOST

STYLE NO.: 22119 PARTS LIST & Hardware List:

1	Canopy	1pc	6	Mounting Screw(2-3/4")	2pcs
2	Universal Bar	1pc	7	Wire Connector	6pcs
3	Ball Finial	2pcs	8	hasp	5pcs
4	Outlet Box Screw(1-1/8")	2pcs	9	Glass	5pcs
5	Green Ground Screw	1pcs	10	Thread Ring	5pcs

*Please make sure you have all the parts indicated above before you begin assembling this item. we suggest a professional electrician for all lighting fixture installations. Please read wiring instructions before you begin assembling and installing your Ceiling Lamp

WARNING: BEFORE INSTALLING, Make sure electricity supply is shut off to avoid a possible electric shock.

ASSEMBLY INSTRUCTIONS

1. Take the parts carefully out of the carton, Place them on a flat surface, and make sure the parts will not be damaged.
2. Remove the Ball finial under the Canopy from the Mounting Screws, and take out the Universal Bar. Attach the Universal Bar to the Outlet Box by using two Outlet Box Screws. (See Figure 1)
3. Adjust the lengths of black rayon wire holding each glass, to the lengths you desire. WE HAVE PRESET THE WIRE LENGTHS IN A CASCADE (as shown in our photo) you are welcome to adjust the cord lengths to your own taste leaving enough to make your connections. Make sure to remove extra wire, making sure you don't leave it attached or tucked in the canopy.
4. Tighten down the wires before corrections. Pull the black rayon wire then tighten it by the hasp.
5. For each of the 5 cords draw all of the wires together as follows:
 - A. Connect all the ground wires together with the supplied ground wire (Green wire),
 - B. Connect all the null wires together with the supplied null wire (White wire)
 - C. Connect all the live wires together with the supplied live wire (black wire)
 Tuck them carefully inside the Outlet box. (See Figure 3)
6. Install Ground Wires in the Universal Bar with the supplied Green Ground Screw.
7. Place the null wire, white wire evenly against the null wire from the Outlet Box and place the live wire, black wire evenly against the live wire from the Outlet Box. (Connecting the Wire---See Figure 2)
8. Attach the Canopy to the Mounting Screws and secure with two Ball Finials (See Figure 1)
9. Put the Glass through the socket, tighten it by the Thread Ring. Repeat to assemble all the other glass.
10. Install 5*60W A19 bulbs (Not Included) into the socket of the fixture.

PO BOX 558/3325 GRASSY HILL RD ROCKY MOUNT VIRGINIA 24151

www.uttermost.com



UTTERMOST

